



UNIVERSAL CONTRACTORS PVA WHITE PRODUCT CODE: PVA00
TECHNICAL DATA SHEET
JULY 2019 REVISION 4

PRODUCT DESCRIPTION

Universal Contractors PVA White is an economical water-based coating

PRODUCT FEATURES AND BENEFITS

Interior and exterior for all primed new and previously coated surfaces

Excellent adhesion

Life expectancy of at least 3 years

Good Hiding Power

PRODUCT INFORMATION

Colour	White only
Surface Appearance	Matt
Resin Base	Acrylic Emulsion
Solids Content	By volume: Approx. 34%
VOC Content	Low VOC content 0,3% to 7,99%
Spreading Rate	Theoretical Spreading Rate: 11,3m ² /litre @ 30 µm DFT Practical Spreading Rate: 6,2m ² /litre @ 30 µm DFT
Recommend WFT & DFT	74 – 103 µm WFT depending on the surface porosity, profile and application method 25 – 35 µm DFT depending on the surface porosity, profile and application Method
Pack Sizes	Available in 5ℓ & 20ℓ



APPLICATION INFORMATION

Application Conditions	Surface Temperatures at 23°C Relative Humidity 50%
Recoating Time	3-4 hours drying time before over coating
Application Methods	Brush & Roller
Thinner	Is ready for use, do not thin.
Cleaning of equipment	Water

SURFACE PREPARATION

NEW SURFACES CEMENT PLASTER, CONCRETE, GYPSUM PLASTER, PRECAST, RHINOLITE, FIBRE CEMENT

The substrates must be clean, dry and sound and free of any contaminants.

Remove all dust, foreign material, fungal and algae growth, which should be treated with Universal Paints Fungal Wash.

Fill and seal all visible cracks with Universal Paints Acrylic Crack Filler (not more than 3mm).

Sand well and remove dust.

Prime using the Universal Water Based Primer (allowing 4 hours to dry) or Universal Pigmented Primer (allowing 16 hours to dry) or Universal Bonding Liquid (allowing 24 hours to dry however it must be overcoated within 72 hours).

Apply 2 coats Universal Contractors PVA White allowing 3-4 hours drying time in between coats.

PREVIOUSLY COATED SURFACES CEMENT PLASTER, CONCRETE, GYPSUM PLASTER, PRECAST, RHINOLITE, FIBRE CEMENT

The substrates must be clean, dry and sound and free of any contaminants.

Remove all loose and flaking paint and sand existing coating.

Remove all dust, foreign material, fungal and algae growth, which should be treated with Universal Paints Fungal Wash.

Fill and seal all visible cracks with Universal Paints Acrylic Crack Filler (not more than 3mm).

Sand well and remove dust.

Spot prime using Universal Water Based Primer (allowing 4 hours to dry) or Universal Pigmented Primer (allow 16 hours to dry) or Universal Bonding Liquid (allowing 24 hours to dry however it must be overcoated within 72 hours) to all bare and repaired areas.

Apply 2 coats Universal Contractors PVA White allowing 3-4 hours to dry between coats.



PRECAUTIONS

For detailed safety information please refer to Material Safety Data Sheet

This product does not contain any toxic substances and contains low levels of VOC

Only use in well ventilated areas and do not eat, drink or smoke whilst using this product

DISCLAIMER

Universal Paints cannot be held liable if the product fails due to improper surface preparation or application