



SUBSTRATE: GYPSUM PLASTER, RHINOLITE, RHINOGLIDE, CRETESTONE, PUTTY PLASTER

DESCRIPTION: UNIVERSAL SUPER ACRYLIC A NEW GENERATION, WATER BASED PURE ACRYLIC, LONG-LIFE, INTERIOR / EXTERIOR, MATT COATING.

SYSTEM TABLE

TECHNICAL DATA	1 ST COAT	2 ND COAT	3 RD COAT	4 TH COAT
PRODUCT NAME	UNIVERSAL WATER BASED PLASTER PRIMER	UNIVERSAL SUPER ACRYLIC	UNIVERSAL SUPER ACRYLIC	
PRODUCT CODE	PRI01	SAC00	SAC00	
LIFE EXPECTANCY	7 YEARS	7 YEARS	7 YEARS	
WB/SB	WATER BASED	WATER BASED	WATER BASED	
SMOOTH/TEXTURE	SMOOTH	SMOOTH	SMOOTH	
COLOUR	WHITE	WHITE & FANDECK	WHITE & FANDECK	
VOLUME SOLIDS %	31	45	45	
FILM BUILD	WFT 129 - 161µm DFT 40 – 50 µm	WFT 67- 89 µm DFT 30 - 40 µm	WFT 67- 89µm DFT 30 - 40µm	
SPREADING RATE DFT	TSR 6,9m ² /lit @45µm PSR 4,1m ² /lit@45µm	TSR 12,9m ² /lit @35µm PSR 7,3m ² /lit@35µm	TSR 12,9m ² /lit@35µm PSR 7,3 ² /lit@35µm	
DRYING TIMES @23°C	2 HOURS	3-4 HOURS	3-4 HOURS	
VOC % GRAMS PER LITRE	0,01 0,10	1,04 14,27	1,04 14,27	
CLEANING	WATER	WATER	WATER	



SURFACE PREPARATION METHOD STATEMENT

Ensure surfaces are dry, sound and free from surface contaminants, e.g. loose particles, dust, oil, etc.

Soft under-cured surfaces may be restored to a sound surface with Universal Bonding Liquid (BON00) thinned 20% by volume with Mineral Turpentine. Allow 16 hours to dry, but not more than 48 hours, before painting.

Make good defects using Universal Acrylic Crack Filler (ACR00). Allow at least 4 hours to dry and sand smooth with 220 grit paper and dust off.

APPLICATION METHOD STATEMENT

Apply 1x coat of [UNIVERSAL Water Based Plaster Primer](#) at a minimum of 129 µm WFT allow 6 hours to dry at 23°C & 50% RH.

Apply 2 x coats of [UNIVERSAL Super Acrylic](#) at a minimum of 67 µm WFT per coat, allowing 3-4 hours drying between coats at 23°C & 50% RH.

FOOT NOTES:

- TSR = Theoretical Spread Rate
- PSR = Practical Spread Rate
- VOC = Volatile Organic Compound
- WFT = Wet Film Thickness
- DFT = Dry Film Thickness
- ERH = Equilibrium Relative Humidity
- RH = Relative Humidity